
TAMPA SCHOOL SAFETY



- 1. Install a raised crosswalk and work with CSX to upgrade crossing safety equipment.
- 2. Refresh crosswalk markings.
- 3. Install double yellow lines on E Osborne Avenue.
- 4. Add a vertical barrier between the roadway and sidewalk to prevent parents/guardians from blocking the sidewalk.
- 5. Convert Cayuga Street from N 31st Street to N 34th Street to one-way westbound and install two speed humps. Consider painting the school mascot or a mural on this segment to emphasize that it is a school zone.
- 6. Convert to an All-Way Stop. Install Stop Sign (R1-1) westbound, Do Not Enter sign (R5-1) eastbound, One Way sign (R6-1), No Right Turn sign (R3-1) northbound, and No Left Turn sign (R3-2) southbound.
- 7. Install signs prohibiting parking on both sides of E Cayuga Street between N 31st Street and the parking lot driveway.
- 8. Install One Way sign (R6-1) and No Right Turn (R3-1) sign.
- 9. Convert crossing to a raised crosswalk. Consider giving the crossing guard a key to manually override the signal.
- 10. Bring existing School Speed Zones into compliance with State Statute.
- 11. Install a raised crosswalk and RRFBs.
- 12. Refresh stop bar markings and consider installing marked crosswalks.
- 13. Remove the school zone sign on N 32nd Street.
- 14. Install sidewalks that intersect railroad tracks at a 90 degree angle. Sidewalks should have detectable warning surfaces before on either side of the tracks. Install dynamic envelopes in the roadway on either side or the tracks.
- 15. Install a railing to encourage users to stay on the sidewalk.
- 16. Add Leading Pedestrian Intervals and bicycle detection at Dr Martin Luther King Jr Boulevard.

Potter Elementary School Cayuga Street Tampa, Florida





